
List of figures

Figure 1	
NT6D39 CPU/Network module	9
Figure 2	
NT8D35 Network module	10
Figure 3	
NT8D11 CE/PE module	11
Figure 4	
NT8D37 IPE module	12
Figure 5	
NT5D21 Core/Network module	13
Figure 6	
NT9D11 Core/Network module	14
Figure 7	
Module cover locking latches	15
Figure 8	
Connecting ISDN BRI terminals to Meridian 1	19
Figure 9	
Connecting Meridian 1 to the MDF	21
Figure 10	
Cross-connecting an SILC port to the office wiring	28
Figure 11	
Cross-connecting a UILC port to the office wiring	29
Figure 12	
Connecting the ISDN BRI terminal to the S/T interface	38

Figure 13	
Connecting the ISDN BRI network termination (NT1) to the U interface	39
Figure 14	
Clock reference cable connection	43
Figure 15	
Connecting the network termination to the U interface and to the S/T interface (in TE mode)	46